

Spy Glasses User Guide

A Special Note for Spy Glasses Users!


To achieve better audio level in the Earpiece, if it is used together with the Spy Glasses, insert the Earpiece into the left ear, because Spy Glasses' transmitting antenna is embedded in the left side of Spy Glasses. To adjust the audio level in the Earpiece, adjust output level in the device, which is used as an audio source – e.g. adjust audio in a phone.

Getting Started

1. Make sure the Spy Glasses are fully charged; otherwise charge them. Charging the battery fully may take up to 2-3 hours. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.

Charging the Spy Glasses:

- Find the round Recharge Hole at the bottom side of the left ear arm of the Spy Glasses
- Connect the charger to a wall outlet.
- Connect the charger cable to the Glasses through the recharging hole.
- The Bluetooth Indicator light is shining red while charging. This indicator is located in the inner side of the left ear



arm of the Spy Glasses.

- Wait 2~3 hours to recharge the battery. When the battery is fully charged, the indicator light turns blue.
 - Disconnect the charger from the Spy Glasses and the wall outlet.
2. Activate Bluetooth service in your phone. Follow the following steps:

Pairing the Spy Glasses with a phone:

- Find the hidden Bluetooth Switch, which is located in the central inner part of the left arm. It is marked for your convenience by a label, which you may unstick to hide it completely.
 - Press and hold the hidden Bluetooth Switch for 3-5 seconds until the Bluetooth Indicator light is continuously displayed with blue light.
 - Now the Bluetooth Spy Glasses are set to a Bluetooth service search mode.
 - Locate the Spy Glasses (the id is T9) in your mobile phone and activate phone headset mode for this Spy Glasses.
 - If your phone prompts a password or key, just type four zeros (0000).
 - Then the indicator light will blink 2 times, that confirms the mobile is paired up with the Spy Glasses.
3. Next time the Spy Glasses will try to pair up themselves automatically with the phone, used last time. To pair it up with another phone, repeat the step 2.

Spy Glasses User Guide

Supported Bluetooth Operations:

To make a voice dial call	Tap the Bluetooth Switch and speak a name after a beep
To end a call	Tap the Bluetooth Switch
To receive a call	Tap the Bluetooth Switch
To reject a call	Press the Bluetooth Switch twice
To redial a last call	Press and hold the Bluetooth Switch until there is a beep
To transfer a call from a paired up phone to Spy Glasses	Press and hold the Bluetooth Switch for 3-5 seconds or use respective function in cell phone.

4. Take a fresh battery supported by the Earpiece and insert it into the Earpiece. Then plug it into your ear. The Earpiece will automatically pair up with the Spy Glasses after battery insertion. For detailed instructions on the Earpiece, please, refer to the Earpiece User Guide.
5. Now the Spy Glasses and the Earpiece are ready to use.
6. After using the Set, remove the battery from the Earpiece. To switch off the Glasses, continuously press the Bluetooth Switch until the Bluetooth Indicator light is off.

Troubleshooting

For any questions regarding Spy Glasses or Earpieces, contact www.gsmspyearpiece.com at info@gsmspyearpiece.com

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all accessories and enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device. Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.

All of the above suggestions apply equally to your device, battery, charger or any enhancement. **If any device is not working properly, contact www.gsmspyearpiece.com at info@gsmspyearpiece.com**

Disclaimer

www.gsmspyearpiece.com operates a policy of continuous development. www.gsmspyearpiece.com reserves the right to make changes and improvements to any of the products described in this document without prior notice. Under no circumstances shall www.gsmspyearpiece.com be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused. The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document.